

## **Ecomass Compounds**

Base Resin	NYLON 6/6 (Polyamide 6/6)
Compound Type	Ecomass Compound 2100 Series - Medium and High Density
Processing Method	Injection Molding

## **Process Guidelines**

Flocess Guidelines			
Processing Conditions	Material Drying		
<ul> <li>Melt Temperature Range</li></ul>	<ul> <li>Dryer Type(s)</li></ul>		
Molding Machine Requirements	Safety / Purging		
<ul> <li>Screw L/D</li></ul>	<ul> <li>Maintain adequate ventilation.</li> <li>Wear safety glasses &amp; protective clothing.</li> <li>Do not mix with other materials.</li> <li>Avoid excessive residence time in the barrel. (Purge if extended residence time is anticipated)</li> <li>Use extreme caution at melt temp. &gt; 350C</li> </ul>		
Abrasion Resistant Screw, Barrel & Check Ring	Purge with high viscosity HDPE or high temperature commercial purge compound as recommended.		

## Notes

## Material must be dried to a Moisture Level of < 0.2% for best property retention

The processor of these materials is advised and cautioned to make an independent determination and assessment of the safety and suitability of the material for the specific use in question and is further advised against relying on the information herein as it may relate to any specific use or application. Because conditions under which this material may be processed, tested or used cannot be anticipated, no warranty is given, either expressed or implied, as to the accuracy or reproducibility of this information or for the fitness of this material for any particular use. This material is sold with the express understanding that purchasers, processors or other users of this material have sole responsibility, through performance of their own testing, to determine the suitability of this material for any particular use.

Ecomass Technologies | 4101 Parkstone Heights Drive, Suite 380 | Austin, Texas 78746 | 512.306.0020

<sup>&</sup>lt;sup>1</sup> Typical Drying time assumes unopened packaging and utilization of a dehumidifying dryer with a dewpoint of -40° with sufficient air flow.

<sup>&</sup>lt;sup>2</sup> Pack time can depend on wall thickness and gate design